


Connect to Victron GX Tank 140



- * Do not connect any power between the two systems.
- * min/max values will need to be set in the Victron.
 - Minimum value 0.0 - 0.4v = Tank Empty
 - Maximum value 4.6v - 5v = Tank full